



NEW FEATURE!

Visual Torque Indicator

Tighten couplings so that the tail of the hose clamp falls in the cross hatched area. This ensures proper installation torque of 80 in/lbs.

Installation:

Start by tightening the 2 inner bands, alternating between the 2 bands in 20 in-lb. increments until reaching 80 in-lbs. Then, move outward towards the next ring of bands and repeat. The bands should always be tightened using a properly calibrated torque wrench rated for 80 in-lbs.

Always verify using a properly calibrated torque wrench.



For complete installation instructions, visit IdealTridon.com.